



McAlpine Untrapped Shower Gullies for Sheet Flooring

Installation and Maintenance Guide

McALPINE SHOWER GULLIES SHOULD ONLY BE INSTALLED BY A COMPETENT PLUMBER AND/OR SPECIALIST FLOORING CONTRACTOR



USG1WH



USG2SS-SL-SC



USG3SS

The above simply illustrate a selection of Gullies available. For full range see enclosed leaflet

IMPORTANT NOTE

The integrity of the Gully is dependent on a good seal between the underside of the sheet flooring and the Gully Body. Many silicone sealants and mastics are available for this purpose. Care should be taken to use only a neutral sealant. Acetoxy sealants must not be used as they may be detrimental to the plastic used in the manufacture of the Gully

INSTALLATION INSTRUCTIONS

1. Unpack the box and check contents
2. Remove the Cover Plate or Grating from the Gully Body and keep safe in the box until required
3. Cut hole in floor to accommodate Gully Body (timber floor max.160mm diameter)
4. Set Gully Body into the floor and ensure that the top surface of the Gully Flange is flush with, or slightly below, the floor surface on which the sheet flooring is to be laid
5. Connect discharge pipe to Gully Outlet and test drainage system for air and water tightness
6. Ensure Clamp Ring is in place secured by the 4 x M6 stainless steel screws provided and insert the Temporary Cover Plate into Gully and secure with the 2 x M4 stainless screws also provided
7. **Concrete Floors** – make good around the Gully ensuring that the Gully Body is fully supported and **NOT** solely supported by the Gully Flange
8. **Timber Floors** - secure Gully to floor surface by drilling out indentations in Flange with 5mm drill and fix with 4 x No.8 stainless steel or plated countersunk head screws (not supplied). Ensure that the Gully Body is fully supported and **NOT** solely supported by the Gully Flange
9. To lay sheet flooring, remove Temporary Cover Plate and Clamp Ring from Gully Body by releasing the 4 x M6 stainless steel screws

10. Lay sheet flooring and carefully cut a hole 110mm in diameter directly over the Gully
11. Ensure a watertight seal is obtained between the underside of the sheet flooring and the Gully Flange with adequate use of an appropriate neutral sealant. Do **not** use acetoxy sealant
12. Clamp sheet flooring to the Gully by securing the Clamp Ring with the 4 x M6 stainless steel screws and replace Temporary Cover Plate
13. Prior to hand over, remove Temporary Cover Plate. A visual inspection of the Gully should be carried out to ensure it is clean and free from debris and then replace with Cover Plate and secure with the 2 x M4 stainless steel screws

ROUTINE MAINTENANCE

REGULAR MAINTENANCE AND CLEANING IS REQUIRED AS FOLLOWS

1. Undo two securing screws and remove Cover Plate or Grating by pulling upwards
2. Flush through the Gully Body with clean water and thoroughly clean all parts
3. Re-assemble the Gully

IT IS RECOMMENDED THAT THIS PROCEDURE SHOULD BE CARRIED OUT AT LEAST EVERY 3 MONTHS.
HOWEVER, MORE FREQUENT MAINTENANCE MAY BE REQUIRED DEPENDING ON USAGE

McAlpine & Co Ltd
Kelvin Avenue
Hillington
Glasgow G52 4LF

www.mcalpineplumbing.com